



User Guide

G22 Series Cloud Managed Switch

Copyright statement

Copyright © 2024-2025 IP-COM Networks Co., Ltd. All rights reserved.

IP-COM is the registered trademark of IP-COM Networks Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Copyright of the whole product as integration, including its accessories and software, belongs to IP-COM Networks Co., Ltd. No part of this publication can be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means without the prior written permission of IP-COM Networks Co., Ltd.

Disclaimer

Pictures, images and product specifications herein are for references only. To improve internal design, operational function, and/or reliability, IP-COM reserves the right to make changes to the products described in this document without obligation to notify any person or organization of such revisions or changes. IP-COM does not assume any liability that may occur due to the use or application of the product or circuit layout(s) described herein. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information and recommendations in this document do not constitute a warranty of any kind, express or implied.

Preface

This guide describes how to configure each feature of the following IP-COM G22 Series cloud managed switch.

This guide applies to: G2205D, G2208D, G2216D, G2224D, G2226F, G2205P-4-63W, G2206P-4-63W, G2210P-8-120W, G2220P-16-250W, G2228P-25-410W.



Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.



In this guide, unless otherwise specified, all screenshots are taken from G2206P-4-63W.

Conventions

The typographical elements that may be found in this document are defined as follows.

Item	Presentation	Example
Cascading menus	>	Navigate to System > Live Users .
Parameter and value	Bold	Set User Name to Tom .
Variable	Italic	Format: <i>XX:XX:XX:XX:XX:XX</i>
UI control	Bold	On the Policy page, click the OK button.

The symbols that may be found in this document are defined as follows.

Item	Meaning
	This format is used to highlight information of importance or special interest. Ignoring this type of note may result in ineffective configurations, loss of data or damage to device.
	This format is used to highlight a procedure that will save time or resources.

More information and support

Visit www.ip-com.com.cn and search for the product model to get your questions answered and get the latest documents.

Revision history

IP-COM is constantly searching for ways to improve its products and documentation. The following table indicates any changes that might have been made since the user guide was released.

Version	Date	Description
V2.3	2025-06-10	Made compatible with G2205P-4-63W V1.0: Updated description for unbinding switchs from cloud
V1.0-V2.2	2024.05-2025.04	Historical versions

Contents

Log in to web UI	1
1.1 Login	1
1.2 Logout	2
1.3 Web UI	3
Get device infomation	5
2.1 Port status	5
2.2 Device summary	6
2.3 Port summary	8
Connect to the internet	10
Manage switches on cloud	13
4.1 Unbind the switch from cloud	13
4.2 Add the switch to IP-COM ProFi	13
Assign VLANs	15
5.1 Overview	15
5.2 VLAN configuration	16
5.3 Example of configuring 802.1Q VLAN	18
Configure DHCP snooping	20
Configure loop guard	23
Configure port aggregation	24
Change management IP/VLAN	26
Change management password	27
Handle maintenance tasks	28
11.1 Upgrade switch firmware	28
11.2 Back up configuration	30
11.3 Restore configuration	31
11.4 Reboot the switch	31
11.5 Reset the switch	32
Change date and time	34
Diagnose the network	36

Configure switching	37
14.1 Port configuration	37
14.2 Port mirroring	39
14.3 Port statistics	40
14.4 Cable testing	41
14.5 Jumbo frames	42
14.6 EEE	42
Network security	43
15.1 IGMP snooping	43
15.2 MAC tables	46
QoS	53
16.1 Port rate limit	53
16.2 QoS policies	54
Manage PoE	65
17.1 View PoE budget and consumption	65
17.2 Enable/Reboot PoE schedule	65
17.3 Change PoE port settings	66
17.4 Change fan mode	67
Control indicators	68
Appendix	69

1 Log in to web UI


1.1 Login

1. Connect the computer to any RJ45 port of the switch using an Ethernet cable.
2. Open a web browser on your computer and enter the switch's IP address in the address bar (not the search bar). Follow the onscreen instructions to log in to the switch's web UI.

The switch supports dual IP addresses: [management IP](#) and [dynamic IP](#). The default management IP is **10.16.16.168**, while the dynamic IP is assigned by the DHCP server.




- Ensure that the computer and the switch are in the same subnet. For example, if the switch's IP address is 10.16.16.168, the computer's IP address can be set to 10.16.16.X (X ranges from 2-254 excluding 168, and is unused).



- When logging in for the first time, use the default password on the label of the switch if a login password is required. For network security, be sure to [change the password](#) after login.
- If the web UI does not appear, try the following solutions:
 - Ensure that the switch is powered on.
 - Ensure that the computer is connected to the switch properly.
 - Ensure that the Ethernet cable is not damaged and meets the specification requirements (generally, ≤100 meters).
 - Ensure that the computer and the switch are in the same subnet. For example, if the switch's [management IP address](#) is 10.16.16.168, the computer's IP address can be set to 10.16.16.X (X ranges from 2-254 excluding 168, and is unused).
 - Ensure that the switch's IP address is unique in the local network.
 - Clear the cache of the web browser or try another web browser.
 - If the problem persists, [reset the switch](#) and try again.

---End

After logging in to the web UI, you can start to configure the switch. The following figure shows the web UI of G2210P-8-120W.




1.2 Logout

After you log in to the switch's web UI, the system will automatically log you out if there is no operation within 5 minutes. Alternatively, you can directly click **Exit** in the top right corner to exit the web UI.

1.3 Web UI

1.3.1 Web layout




The web UI can be divided into four parts: level-1 navigation bar, level-2 navigation bar, tab, and the configuration area.













No.	Name	Description
1	Level-1 navigation bar	
2	Level-2 navigation bar	Used to display menu items in the form of a navigation tree that allows you to access functions of the switch.
3	Tab	
4	Configuration area	Used to enable you to view and modify configuration.

1.3.2 Common buttons

The following table describes the common buttons on the switch's web UI.

Button	Description
	
	Used to save and apply the current configuration.
	
	Used to restore the original configuration without saving the configuration on the current page.

Button	Description
	Used to view help information for the corresponding function.
	Used to view help information for the parameter.
	Used to add rules.
	Used to delete rules.
	Used to clear rule configuration or data on the current page.
	Used to modify rules on the current page.
	<p>Used to expand or collapse the port status bar.</p> <p> Tip</p> <p>Generally, the button is located at the top of the port configuration page.</p>
	<p>Enter the port number to select the port. Example: 1-10,12,14.</p> <ul style="list-style-type: none"> – To select continuous ports, such as port 1 to port 10, enter 1-10 or drag the mouse to select ports 1-10. – To select discontinuous ports, such as ports 12 and 14, enter 12 and 14 or click ports 12 and 14. – To select both continuous and discontinuous ports, such as port 1 to port 10, ports 12 and 14, enter 1-10, 12, 14, or drag the mouse to select ports 1-10 and then click ports 12 and 14.
	Used to select all ports.

2 Get device information


- Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.
- In this chapter, G2210P-8-120W is used for illustration.

To access the page:

- On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
- Navigate to **Home**.

2.1 Port status

On the top of the **Home** page, you can view the connection status, port status and mode, connection speed and duplex, sending and receiving rates and PVID just by hovering your mouse over a port.



Parameter description

Name	Description
Port	Specifies the ID of the port.
Status	Specifies the usage status of the port.
Configured Speed/Duplex	Specifies the configured connection rate and duplex mode of the port.
Actual Speed/Duplex	Specifies the actual connection rate and duplex mode of the port.

Name	Description
Sending Rate	Specifies the sending rate of the port.
Receiving Rate	Specifies the receiving rate of the port.
PVID	Specifies the VLAN ID to which the port belongs by default. When a port receives untagged packets, they are forwarded to a specific VLAN based on the PVID.

2.2 Device summary

On the **Device Summary** module of the **Home** page, you can view basic device information and access commonly used configurations.

When multiple DHCP servers are detected in the network, an alarm will be displayed in the upper right corner of the **Device Summary** module.



If [DHCP Client](#) is disabled on the switch, the DHCP alarm function will not take effect.

Device Summary

Multiple DHCP servers exist ⓘ

Device Model	G2210P-8-120W	System Time	2024-10-29 06:48:55	VLAN	Configured	Set
Device Name	G2210P-8-120W	Uptime	2m 4s	DHCP Snooping	Not Configured	Set
Firmware Version	V64.47.11.34(3493)	Management IP	10.16.16. 168	IGMP Snooping	Not Configured	Set
Hardware Version	V1.0	Dynamic IP	192.168.0.180	Port Aggregation	Not Configured	Set
Management VLAN	1	MAC Address		Loop Guard	Not Configured	Set
Cloud Management	Connected	SN		Port Mirroring	Not Configured	Set

By clicking the ⓘ icon, you can view more details about the alarm, including the VLAN ID, port, DHCP server IP address and MAC address.

Multiple DHCP servers exist ⓘ		
Port	IP Address	MAC Address
7	192.168.0.252	10:16:88:E7:9F:7A
1	192.168.1.1	50:0F:F5:E1:41:F0

Parameter description

Name	Description
Device Model	Specifies the model of the switch.
Device Name	<p>Specifies the name of the switch.</p> <p>By default, it displays as the device model. Click the device name to change it on the Device Info page.</p>
Firmware Version	Specifies the firmware version of the switch.
Hardware Version	Specifies the hardware version of the switch.
Management VLAN	<p>Specifies the management VLAN of the switch.</p> <p>When 802.1Q VLAN is enabled, the management VLAN defaults to VLAN 1. Change the value as required.</p>
Cloud Management	<p>Specifies whether the switch is connected to IP-COM ProFi Cloud platform.</p> <p>Click the connection status to configure cloud management on the Device Info page.</p>
System Time	<p>Specifies the current system time of the switch.</p> <p>Click the system time to change the setting on the Maintenance page.</p>
Uptime	Specifies how long the switch has been running since its last launch.
Management IP	<p>Specifies the management IP address of the switch. Default: 10.16.16.168. Change the setting as required.</p> <p>Computers in the LAN connected to the management VLAN member port can use this IP address to log in to the switch's web UI.</p>
Dynamic IP	<p>Specifies the dynamic IP address of the switch. By default, it is obtained from the LAN DHCP server. Computers in the LAN connected to the management VLAN member port can use this IP address to log in to the switch's web UI.</p> <p>Click the dynamic IP address to change the setting on the Device Info page.</p>
MAC Address	Specifies the physical address of the switch.
SN	Specifies the serial number of the switch.
VLAN	
DHCP Snooping	<p>Specifies the status of the configuration.</p> <p>Click Set to edit the configuration.</p>
IGMP Snooping	

Name	Description
Port Aggregation	
Loop Guard	
Port Mirroring	


2.3 Port summary

On the **Port Summary** module of the **Home** page, you can view a summary of the status, VLAN, PoE consumption and network extension of all ports on the switch.

To access detailed configuration, click the web URL when necessary.




Only when [802.1Q VLAN](#) is enabled, VLAN information can be viewed.



Port Summary									
Port	Port Status					VLAN Info		Network Extension	PoE Status
	Status	Speed/Duplex		Rate(Kbps)		PVID	Port Type		
		Configured	Actual	Rx	Tx				
1	Disconnected	Auto/Auto	--	0.00	0.00	1	Access	Disabled	0.00W
2	Connected	Auto/Auto	1000M/Full-Du...	0.67	0.00	1	Access	Disabled	0.00W
3	Disconnected	Auto/Auto	--	0.00	0.00	1	Access	Disabled	0.00W
4	Connected	Auto/Auto	1000M/Full-Du...	0.00	0.34	1	Access	Disabled	3.39W
5	Disconnected	Auto/Auto	--	0.00	0.00	1	Access	Disabled	0.00W
6	Connected	Auto/Auto	1000M/Full-Du...	0.00	0.34	1	Access	Disabled	0.00W
7	Disconnected	Auto/Auto	--	0.00	0.00	1	Access	Disabled	0.00W
8	Disconnected	Auto/Auto	--	0.00	0.00	1	Access	Disabled	0.00W

Parameter description

Name		Description
Port		Specifies the ID of the port.
	Status	Specifies whether the port is enabled.
	Speed/Duplex (Configured)	Specifies the configured connection rate and duplex mode of the port.
	Speed/Duplex (Actual)	Specifies the actual connection rate and duplex mode of the port.
		 Tip "--" indicates that the port is not connected or the negotiation failed.
Port Status	Rx	Specifies the receiving rate of the port.
	Tx	Specifies the sending rate of the port.
	PVID	Specifies the VLAN ID to which the port belongs by default. When a port receives untagged packets, they are forwarded to a specific VLAN based on the PVID.
	VLAN Info	Specifies the type of the port.
	Port Type	<ul style="list-style-type: none"> – Access: An access port can join only one VLAN and send untagged packets. This type of port is used to connect client devices (such as computers). – Trunk: A trunk port can allow multiple VLANs to pass, and receive or send packets from multiple VLANs. This type of port is used for cascading ports between switches.
Network Extension		Specifies whether network extension is enabled.
PoE Status (Only available on PoE switches)		Specifies the PoE output status of the port.

3 Connect to the internet

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

By default, the switch will automatically obtain an IP address to connect to the internet. To change the switch's IP address and DNS acquisition method, take the following steps:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Device Info**.
3. Enable or disable **DHCP Client**.
4. When **DHCP Client** is disabled, enter an IP address, subnet mask and gateway for the switch.
5. Enable or disable **Auto DNS**.
6. When **Auto DNS** is disabled, enter a primary and secondary DNS server address for the switch.
7. Click **Save**.

Device Info ?

Cloud Management

Device Name

G2220P-16-250W

Device Model

G2220P-16-250W

Firmware Version

V64.47.11.28(3292)

Hardware Version

V1.0

MAC Address

Device SN

DHCP Client

Disabling DHCP to obtain IP addresses disables the multiple DHCP alarm function.

IP Address

192.168.10.6

Example: 192.168.1.2

Subnet Mask

255.255.255.0

Example: 255.255.255.0

Gateway

192.168.10.10

Auto DNS

Primary DNS

192.168.10.10


Secondary DNS

Save

*The figure shows an example of configuring the switch to automatically obtain an IP address and DNS server address.

---End

Parameter description

Name	Description
DHCP Client	<p>Used to enable or disable the switch to automatically obtain network parameters from the DHCP server.</p> <ul style="list-style-type: none">– When enabled, the switch automatically obtains network parameters from the DHCP server.– When disabled, you need to manually configure network parameters for the switch. <ul style="list-style-type: none">• IP Address: IP address of the switch.• Subnet Mask: Subnet mask corresponding to the switch's IP address.• Gateway: Gateway address of the switch. <p> Tip</p> <p>When this function is disabled, the DHCP alarm function will be disabled simultaneously.</p>
Auto DNS	<p>Used to enable or disable the switch to automatically obtain a DNS server address. It is enabled by default.</p> <ul style="list-style-type: none">– When enabled, the switch automatically obtains a DNS server address from the DHCP server.– When disabled, you need to manually configure a primary and secondary DNS server address for the switch. <ul style="list-style-type: none">• Primary DNS: Primary DNS server address of the switch.• Secondary DNS: (Optional) Secondary DNS server address of the switch.

4 Manage switches on cloud


Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

IP-COM ProFi is an IP-COM company-owned cloud platform where you can manage IP-COM devices with cloud management support. IP-COM ProFi is available in mobile app and web versions (<https://imsen.ip-com.com.cn>), and the data is interoperable.

4.1 Unbind the switch from cloud

By default, cloud management is enabled. After adding the switch to the cloud platform, if you want to use another account to manage the switch or no longer want to manage the switch through the cloud platform, take the following steps:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Device Info**.
3. Disable **Cloud Management**.
4. Click **OK** to confirm the prompt.



5. Click **Save** to save your settings.

---End

4.2 Add the switch to IP-COM ProFi

After cloud management is enabled, you can add a switch to IP-COM ProFi through either of two methods below.

Once the switch is added, configuration changes can be made either on the IP-COM ProFi cloud

platform or the switch's local web UI. The configuration last modified will come into effect.



Before managing the switch on the IP-COM ProFi cloud platform, ensure that the switch is connected to the internet.



Or



4.2.1 Add the switch via Wi-Fi

1. Download the IP-COM ProFi App to your mobile device by scanning the QR code or searching for **IP-COM ProFi** in **Google Play** or **App Store**.
2. Connect your mobile device to the switch's Wi-Fi network.
3. Open your IP-COM ProFi App, and tap the project (or create one if no projects exist) to which you want to add the switch.
4. Tap the pop-up window when the switch is detected, and add the switch to the project.



If the pop-up window does not appear, tap  and follow the instructions on your screen.

4.2.2 Remotely add the switch



During configuration, ensure that the mobile device is connected to the internet.

1. Download the IP-COM ProFi App to your mobile device by scanning the QR code or searching for **IP-COM ProFi** in **Google Play** or **App Store**.
2. Open your IP-COM ProFi App, and tap the project (or create one if no projects exist) to which you want to add the switch.
3. Remotely add the switch to the project.

---End

5 Assign VLANs

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

5.1 Overview

Virtual Local Area Network (VLAN) is a technology that divides devices in LAN into different logical, instead of physical, network segments to realize virtual working groups. VLANs allow a network station constituted by switches to be logically segmented into different domains for broadcast separation. All members in a VLAN are treated as in the same broadcast domain and communicate as if they were on the same network segment, regardless of their physical locations. Different VLANs cannot intercommunicate directly. Inter-VLAN communication can only be achieved using a router or other layer-3 devices that are able to perform layer-3 forwarding.

This switch supports 802.1Q VLAN and can communicate with devices that support 802.1Q VLAN in VLAN as well. 802.1Q VLAN is defined by IEEE 802.1q protocol. With 802.1Q VLAN, the switch can process packets by identifying the tags in packets.

This switch supports two 802.1Q VLAN port types:

- Access: An access port can join only one VLAN. This type of port is used for connecting the computer.
- Trunk: A trunk port can receive and send packets belonging to multiple VLANs. This type of port is used for connection between switches.

Methods of each port type to process packets are shown as follows.

Port type	Receiving tagged data	Receiving untagged data	Sending data
Access port			Strip the tag from the packet and then forward it
Trunk port	Forward data to the ports with VLANs assigned based on the VLAN ID	Forward data to the ports with VLANs assigned based on the PVID	VLAN ID = PVID of the port, strip the tag from the packet and then forward it
			VLAN ID ≠ PVID of the port, retain the tag in the packet and then forward it

5.2 VLAN configuration

Enable 802.1Q VLAN

Navigate to **Basic Function > VLAN**. Here you can enable or disable 802.1Q VLAN on the switch.

The 802.1Q VLAN function is disabled by default. When it is disabled, the switch is in VLAN transparent transmission mode and can forward all VLAN data. After it is enabled, you can [create](#) and [configure](#) a VLAN, as shown below.



Enabling 802.1Q VLAN will remove all dynamic MAC addresses in the MAC table. Once it is enabled, disabling this function will remove the current VLAN configuration on the switch and all MAC addresses in the MAC table. Operate when necessary.

Create VLANs

When [802.1Q VLAN](#) is enabled, you can view, create or delete a VLAN in the **VLAN Member** module.

To ensure that the switch in factory condition can communicate normally, the system creates 1 VLAN by default. All ports belong to this VLAN by default, the VLAN ID is 1, and the IP address defaults to 10.16.16.168. This VLAN cannot be deleted.

802.1Q VLAN ?

- * When 802.1Q VLAN is disabled, all ports forward packets only based on the destination MAC addresses, without changing VLAN information in the packets.
- * When 802.1Q VLAN is enabled, up to 32 VLANs can be created.

802.1Q VLAN ☒

VLAN Member

AddDelete

<input type="checkbox"/>	VLAN ID	VLAN Name	Port	Operation
<input type="checkbox"/>	1	default ✎	1-20	

Parameter description

Name	Description
VLAN ID	Specifies the ID of the VLAN. By default, VLAN 1 is considered as the management VLAN.
VLAN Name	Specifies the name of the VLAN. If it is not set, the default name is "VLAN and four-digit VLAN ID". For example, when the VLAN ID is 3, the VLAN name is VLAN0003. Click to edit.

Name	Description
Port	Specifies the port that allows the corresponding VLAN to pass.

Configure VLANs

When [802.1Q VLAN](#) is enabled, you can achieve VLAN isolation by configuring the port type, PVID, and allowed VLANs of each port on the switch in the **Edit Port** module.

Edit Port					Edit
Port	Port Type	PVID	Tagged	Operation	
1	Access	1	--	Edit	
2	Access	1	--	Edit	
3	Access	1	--	Edit	
4	Access	1	--	Edit	
5	Access	1	--	Edit	

Parameter description

Name	Description
Port	Specifies the ID of the port.
Port Type	<p>Supported port types: Access and Trunk.</p> <ul style="list-style-type: none"> Access: An access port can join only one VLAN and send untagged packets. This type of port is used to connect to client devices, such as computers. Trunk: A trunk port can receive and send packets belonging to multiple VLANs. This type of port is used as a cascade-connected port between switches.
PVID	<p>Specifies the VLAN ID to which the port belongs by default. The PVID of each port defaults to 1.</p> <p>When a port receives untagged packets, they are forwarded to a specific VLAN based on the PVID.</p>
Tagged	<p>Specifies the VLAN that the port allows to pass.</p> <p>If the VLAN ID of the tagged packets received by the port is the same as the tagged VLAN, the port retains the tags of the packets and transmit them.</p>

5.3 Example of configuring 802.1Q VLAN


Network requirement

The staff in the Finance department and Marketing departments of a company work on the second floor, while the servers for these two departments are on the third floor. Now it is required that internal communication and server access is available within the departments, but the departments cannot communicate with each other.

Solution

Configure an 802.1Q VLAN for two switches:

- Create two VLANs for the switches. Assign the ports connected to the Finance department's devices to VLAN 5, and the ports to the Marketing department's devices to VLAN 7.
- Add the ports that connect two switches to both VLAN 5 and VLAN 7.



Configuration procedure

I. Configure Switch A

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **Basici Function > VLAN**.
3. Enable **802.1Q VLAN**.

4. In the **VLAN Member** module, click **Add** and enter the following parameters on the pop-up window, and then click **OK**.
 - Set **VLAN ID** to **5**.
 - Set **VLAN Name** to **Finance**.
5. Repeat step [4](#) and add another VLAN with the **VLAN ID** of **7** and **VLAN Name** of **Marketing**.

802.1Q VLAN ?

802.1Q VLAN ☒

VLAN Member

AddDelete

<input type="checkbox"/>	VLAN ID	VLAN Name	Port	Operation
<input type="checkbox"/>	1	default ✎	1–20	
<input type="checkbox"/>	5	Finance ✎	--	Delete
<input type="checkbox"/>	7	Marketing ✎	--	Delete

6. In the **Edit Port** module, configure the VLANs.
 - 1) Locate the port 5 and click **Edit**. Set **PVID** to **5**.
 - 2) Locate the port 7 and click **Edit**. Set **PVID** to **7**.
 - 3) Locate the port 1 and click **Edit**. Set **Type** to **Trunk**, and **Tagged** to **5,7**.

Edit Port

Edit

Port	Port Type	PVID	Tagged	Operation
1	Trunk	1	5,7	Edit
2	Access	1	--	Edit
3	Access	1	--	Edit
4	Access	1	--	Edit
5	Access	5	--	Edit
6	Access	1	--	Edit
7	Access	7	--	Edit

II. Configure Switch B

Refer to the steps of [configuring Switch A](#).

---End

Verification


The staff can access the server of their department, but cannot access the server of the other department. The staff in the same department can communicate with each other but cannot communicate to the staff of other departments.

6 Configure DHCP snooping

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

After DHCP snooping is enabled on the switch, users can only obtain IP addresses through DHCP servers connected to trusted ports and unauthorized DHCP servers will be blocked.

As shown in the figure below, a company has deployed switches on the office floor. Switch port 2 is connected to an employee's computer, which uses DHCP to obtain IP addresses. An authorized DHCP server is deployed on the network, and switch port 1 is connected to the authorized DHCP server.



At present, unauthorized DHCP server access often occurs on office floors, causing employee computers to obtain wrong addresses and being unable to access the internet, or causing the employee's computer to obtain a conflicting address.

Procedure:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **Basic Function > DHCP Snooping**.
3. Enable **DHCP Snooping**.
4. Select port 1.
5. Click **Save**.

DHCP Snooping ?

DHCP Snooping ☒

Choose Trusted Port

Unavailable 1 ☐ All Ports

1 3 5 7 9 11 13 15 17

2 4 6 8 10 12 14 16 18 19 20


* Drag with the left mouse button to get multiple ports selected. Left-click on a port to select or deselect.

Save

---End

After completing the above configuration, the employee's computer can only obtain IP address information from authorized DHCP servers, and unauthorized DHCP servers cannot assign IP address information to the employee's computer.

Parameter description

Name	Description
	<p>A trusted port can forward the received DHCP packets and is used to connect to the authorized DHCP server.</p> <p> Tip</p> <p>When DHCP snooping is enabled, the following situations occur by default:</p> <ul style="list-style-type: none">– If the switch obtains an IP address from the DHCP server in the LAN and can ping any website (such as www.google.com), and the port connected to the DHCP server is the same as the port connected to the upstream gateway, this port is marked in green and set as trusted by default. If the port connected to the DHCP server is different from the port connected to the upstream gateway, these two ports are marked with a rectangle symbol and recommended as trusted ports.– If the switch obtains an IP address from the DHCP server in the LAN but cannot ping any website, the port connected to the DHCP server is marked with a rectangular symbol and recommended as trusted port.– If the switch does not obtain an IP address from the DHCP server but can ping any website, the port connected to the upstream gateway is marked with a rectangular symbol and recommended as trusted port.– If the switch does not obtain an IP address from the DHCP server and cannot ping any website, set all ports as trusted and they will be marked in green.
Choose Trusted Port	

7 Configure loop guard

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

After loop guard is enabled, the port where the loop occurs will be blocked and no packets will be forwarded if a loop exists on the switch. After the loop is eliminated, the port will automatically return to the forwarding state.


On the **Basic Function > Loop Guard** page, you can enable or disable loop guard on the switch. This function is disabled by default.

8 Configure port aggregation

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

Port aggregation is used to converge multiple physical ports into a logical aggregation group, and multiple physical links in one aggregation group are regarded as one logical link. The port aggregation function binds multiple physical links into one logic link and enables them to share traffic load for each other, thus increasing the bandwidth between the switch and peer device. Meanwhile, each member in an aggregation group backs up each other's data dynamically, improving connection reliability.

The network topology of port aggregation is shown as follows.




Note

- In the same aggregation group, all member ports must be set to the same configurations with respect to QoS, VLAN and port configuration.
 - Mirrored ports cannot be added to aggregation groups.
 - The number of aggregation groups varies by the switch model. Please refer to the actual interface.
-

On the **Basic Function > Port Aggregation** page, to configure the aggregation group, click **Edit**. To delete its configuration, click **Delete**. Port aggregation groups cannot be added or deleted.

Port Aggregation ?			
Aggregation Algorithm		src-dst-mac-ip-port	
Aggregation Group	Aggregation Mode	Member Port	Operation
1	Static	--	Edit Delete
2	Static	--	Edit Delete
3	Static	--	Edit Delete
4	Static	--	Edit Delete

Parameter description

Name	Description
Aggregation Algorithm	Specifies the routing algorithm for static aggregation groups:
	– src-dst-mac-ip-port : Member ports in the aggregation group share the load based on the source MAC address, destination MAC address, source IP address, destination IP address, TCP or UDP source port number and destination port number in the received packet.
	– src-dst-mac : Member ports in the aggregation group share the load based on the source MAC address and destination MAC address in the received packet.
	– src-dst-ip : Member ports in the aggregation group share the load based on the source IP address and destination IP address in the received packet.
Aggregation Group	Specifies the ID of aggregation groups. Editing is not allowed.
Aggregation Mode	Specifies the aggregation mode of the aggregation group. Only static aggregation mode is supported, that is, all member ports in the aggregation group converge into one logical port.
	 Note The aggregation mode of the switch needs to be the same as that of the peer device. Otherwise, the data cannot be forwarded properly or a loop occurs.
Member Port	Specifies the member ports of the aggregation group.

9 Change management IP/VLAN

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

The default management IP address is 10.16.16.168, and there is no management VLAN by default unless VLAN is configured. When VLAN is enabled on the switch, management VLAN defaults to 1. Users in the LAN can access the switch web interface through the management IP address.

To change the management VLAN or IP address, take the following steps:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **Basic Function > Home**.
3. On the **Device Summary** module, enter a new management VLAN and IP address as required.
4. Wait for your configuration to take effect.

The screenshot displays the 'Device Summary' configuration page. On the left, under 'Device Model' G2220P-16-250W, the 'Management VLAN' is set to 1. On the right, under 'System Time' 2024-10-31 06:19:18, the 'Management IP' is 10.16.16.168. Both the 'Management VLAN' dropdown and the 'Management IP' field are highlighted with a dashed blue border. Other fields include 'Firmware Version' V64.47.11.28(3292), 'Hardware Version' V1.0, 'Dynamic IP' with a '--Set-->' link, 'MAC Address', 'SN', and 'Cloud Management' status 'Disconnected'.

---End


After changing the management IP address and VLAN, you need to connect to the new management VLAN and access the new management IP address for login.

10 Change management password

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

For the first time that you log in to the switch's web interface, you must set a management password. To safeguard your network, periodically change the password as follows:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Account Management**.
3. For **Old Password**, enter your current management password.
4. For **New Password**, enter a new password.
5. For **Confirm Password**, enter your new password again.
6. Click **Save**.



The screenshot shows a web interface titled "Account Management" with a red question mark icon. It contains three input fields for "Old Password", "New Password", and "Confirm Password", each with a toggle icon to the right. Below the fields is a red "Save" button.

---End

After changing the password, you will be redirected to the login page. Enter the password you just set to log in to the switch's web interface.

11 Handle maintenance tasks

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

11.1 Upgrade switch firmware

You can upgrade the firmware through either a [local upgrade](#) or [cloud upgrade](#).






To avoid damage to the switch, ensure stable power supply to the switch during the upgrade.

Use local upgrade

Procedure:

1. Download the proper firmware from <https://www.ip-com.com.cn>. Generally, the unzipped upgrade file is suffixed with **.bin**.
2. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
3. Navigate to **System Settings > Maintenance**.
4. Click **Upgrade**, select **Keep Current Configuration** if needed, and click **Local Upgrade** to upload the upgrade file.





5. Click **OK**.

---End


The firmware upload and update progress bars show in turn until they finish.


Use cloud upgrade

Once successfully [connected to the network](#), the switch automatically checks for firmware updates. When the system prompts "New version available," upgrade the firmware from the cloud.

Procedure:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Maintenance**.
3. Click **Upgrade**, select **Keep Current Configuration** if needed, and click **Cloud Upgrade**.






---End

The firmware upload and update progress bars show in turn until they finish.

11.2 Back up configuration

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Maintenance**.
3. Click **Local Backup**.



4. Click **OK**.

---End

The configuration file suffixed with **.cfg** will be download to the local computer.



If an "insecure donwload" reminder pops up, select "Keep" to download the file.


11.3 Restore configuration

You can import the backup configuration file into the switch to restore the switch to the previous configuration status.



The switch does not verify the configuration file. Please make sure that the configuration file is correct before importing it. The suffix of the configuration file is **.cfg**.

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Maintenance**.
3. Click **Select File** and import the configuration backup into the switch.




---End

The switch will reboot to make the configuration take effect when the progress bar is filled.

11.4 Reboot the switch

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Maintenance**.
3. Click **Reboot**.



4. Click **OK**.

---End

The switch will reboot when the progress bar is filled.

11.5 Reset the switch

If you fail to locate a fault, or forget your username or password when you log in the web UI of the switch, you can restore the switch to factory settings. Once the switch is reset, the management IP address of the switch defaults to 10.16.16.168. If a management password is required for login, use the password on the label on the switch.


Both [firmware reset](#) and [hardware reset](#) are supported.



- To avoid damage to the switch, ensure stable power supply to the switch during factory reset.
- Resetting the switch will remove all user configuration. Operate when necessary.

Use firmware reset

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Maintenance**.
3. Click **Reset**.



4. Click **OK**.

---End

The switch will be restored to factory settings and rebooted when the progress bar is filled.

Use hardware reset

When the system indicator (**SYS**) is blinking, press and hold the reset button (**RST**, **Reset**, **RESET**) with a needle-like object for about 7 seconds, and then release it when all indicators are solid on. When the system indicator blinks again, the switch is restored to factory settings.

12 Change date and time

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

By default, the switch is in local time mode. After [connecting to the IP-COM ProFi cloud platform](#), the switch automatically synchronizes the time to the project that it added to.



To ensure that time-based functions of the switch (such as [PoE schedule](#)) operate normally, connect the switch to the IP-COM ProFi cloud platform or synchronize the switch time with the internet.

To synchronize the switch system time with the internet:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Maintenance**.
3. Select **Internet Time**.
4. Select the time zone where the switch locates.
5. Click **Save**. The following figure is for reference only.

System Time

Current Time 2024-09-03 21:36:35

☐ Local Time ☒ Internet Time

Time Zone (GMT+12:00) Wellington ▼

Save

---End

The switch will be synchronized to the network time in the selected time zone.

Parameter description

Name	Description
Sync Local Time	Used to synchronize the time of the management computer to the switch.

13 Diagnose the network


Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

By running Ping tests, you can test the network connectivity and quality.

Procedure:

Assume you want to test the network connectivity between the switch and Google website.

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Diagnostics**.
3. For **Target IP Address**, enter the IP address domain name of the target device, which is **www.google.com** in this example.
4. (Optional) For **Ping Packets**, set the number of echo request packets. Default value is retained in this example.
5. (Optional) For **Packet Size**, set the size of the echo request packets. Default value is retained in this example.
6. Click **Start**.



The screenshot shows a 'Ping Test' configuration window. It contains three input fields: 'Target IP Address' with the value 'www.google.com' and a hint '(IP address or domain name)', 'Ping Packets' with the value '5' and a hint '(Range: 1 to 100)', and 'Packet Size' with the value '64' and a hint 'B (Range: 18 to 512)'. At the bottom is a red 'Start' button.

Ping Test	
Target IP Address	<input type="text" value="www.google.com"/> (IP address or domain name)
Ping Packets	<input type="text" value="5"/> (Range: 1 to 100)
Packet Size	<input type="text" value="64"/> B (Range: 18 to 512)
<input type="button" value="Start"/>	

---End

Wait for the Ping result to appear in **Detection Result**.

14 Configure switching



Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.





14.1 Port configuration

On the **Switching > Ports** page, you can view and configure port parameters.

Port Configuration ?									
Port	Status	Configured Speed/Duplex	Actual Speed/Duplex	Network Extension	Configured Flow Control	Actual Flow Control	Port Isolation	Inbound/Outbound Traffic	Operation
1	Disconnected	Auto/Auto	--	Disabled	Disabled	Disabled	Disabled	0.00B/0.00B	Edit
2	Connected	Auto/Auto	100M/Full-...	Disabled	Disabled	Disabled	Disabled	2.11MB/12.75M	Edit
3	Disconnected	Auto/Auto	--	Disabled	Disabled	Disabled	Disabled	0.00B/0.00B	Edit
4	Disconnected	Auto/Auto	--	Disabled	Disabled	Disabled	Disabled	0.00B/0.00B	Edit
5	Disconnected	Auto/Auto	--	Disabled	Disabled	Disabled	Disabled	0.00B/0.00B	Edit
6	Connected	Auto/Auto	1000M/Full-...	Disabled	Disabled	Disabled	Disabled	2.13MB/5.19M	Edit
7	Disconnected	Auto/Auto	--	Disabled	Disabled	Disabled	Disabled	0.00B/0.00B	Edit
8	Connected	Auto/Auto	1000M/Full-...	Disabled	Disabled	Disabled	Disabled	4.67MB/5.07M	Edit

Parameter description

Name	Description
Port	Specifies the ID of the port.
Status	<p>Enabled by default. Click Edit to enable or disable the port.</p> <p> Tip</p> <p>No Change indicates that the port status remains unchanged.</p>
Configured Speed/Duplex	<p>Configured connection speed and duplex mode of the port. Click Edit to change.</p> <p> Tip</p> <p>No Change indicates that the connection rate and duplex mode remain unchanged.</p>

Name	Description
Actual Speed/Duplex	<p>Used to display the actual connection speed and duplex mode of the port.</p> <p> Tip</p> <p>"--" indicates that the port is not connected or the negotiation failed.</p>
Network Extension	<p>Disabled by default. Click Edit to enable or disable network extension.</p> <p>After enabling this function, the data transmission distance of the switch port can be extended, which brings great convenience to network deployment. When this function is enabled on the port, it only supports 10Mbps full and half-duplex communication, but the port data transmission distance can exceed 100 meters, up to 250 meters.</p> <p>When the switch needs to be connected to client devices at a long distance (>100 meters), it is recommended to enable this function.</p> <p> Tip</p> <ul style="list-style-type: none"> – No Change indicates that the function status remains unchanged. – To ensure the network extension effect, use CAT5e or above Ethernet cables, and set the speed and duplex mode of the peer device port to Auto. If the peer device is a network camera, adjust its code stream to below 8 Mbps to ensure the timeliness of video data transmission.
Configured Flow Control	<p>Configured flow control mode of the port. It is disabled by default. No Change indicates that the function status remains unchanged.</p> <p>When flow control is enabled on both the switch and the peer device, if congestion occurs on a port of the switch, the port will send a flow control (Pause) frame to the peer device. After receiving the flow control frame, the peer device will pause sending data to the port of the switch. Similarly, when a port of this switch receives a flow control frame, the port will also stop sending data to the outside.</p> <p> Note</p> <p>Enabling flow control can avoid packet loss caused by inconsistent sending and receiving rates, but the communication rate between the data source port and other devices will be affected. Use this function with caution on ports connected to the internet.</p>
Actual Flow Control	<p>Used to display the actual flow control of the port.</p>
Port Isolation	<p>Disabled by default. Click Edit to enable or disable port isolation.</p> <p>When port isolation is enabled, isolated ports are isolated from each other and can only communicate with non-isolated ports.</p> <p> Tip</p> <p>No Change indicates that the function status remains unchanged.</p>

Name	Description
Inbound/Outbound Traffic	Used to display data traffic received or sent by the port.

14.2 Port mirroring

Port mirroring is a method of copying and sending network packets from a port or multiple ports (source ports) to a specified port (destination port) of the switch. The destination port is commonly connected to a data monitoring device, enabling you to monitor data traffic, analyze performance, and diagnose faults.

On the **Switching > Port Mirroring** page, you can click **Edit** and configure port mirroring rules.



You can configure only one port mirroring rule.

Port Mirroring			
Source Port	Mirroring Direction	Destination Port	Operation
--	--	--	Edit Clear



Port Mirroring

Source Port

Unavailable

Port number

All Ports

1 3 5 7 9 11 13 15 17

2 4 6 8 10 12 14 16 18 19 20

* Drag with the left mouse button to get multiple ports selected. Left-click on a port to select or deselect.

Mirroring Direction

Please select

Destination Port

Please select

(The destination port must be different from the mirroring source port.)

Cancel

OK

Parameter description

Name	Description
Source Port	Specifies the port to be mirrored. Multiple ports can be selected.

Name	Description
	Specifies the packet type.
Mirroring Direction	<ul style="list-style-type: none"> – Ingress: Packets received by source ports will be copied to the destination port. – Egress: Packets transmitted by source ports will be copied to the destination port. – Two-way: Packets transmitted and received by source ports will be copied to the destination port.
Destination Port	Packets of source ports will be copied to this port. A mirroring group can contain only one destination port.

14.3 Port statistics

On the **Switching > Port Statistics** page, you can view the status, connection speed and duplex mode and packet statistics of each port, or clear the packet statistics of each port.

To clear the packet statistics of each port, click **Clear**. To refresh the packet statistice of each port, click **Refresh**.

Port Statistics

Clear

Refresh

Port	Port Rate	Sent				Received			
		Rate (Kbps)	Bytes	Packets	Wrong Packets	Rate (Kbps)	Bytes	Packets	Wrong Packets
1	Disconnected	0.00	0	0	0	0.00	0	0	0
2	Disconnected	0.00	0	0	0	0.00	0	0	0
3	1000M/FDX	21.02	2283446	7179	0	2.63	4296283	16976	0
4	Disconnected	0.00	0	0	0	0.00	0	0	0
5	Disconnected	0.00	0	0	0	0.00	0	0	0
6	Disconnected	0.00	0	0	0	0.00	0	0	0
7	Disconnected	0.00	0	0	0	0.00	0	0	0
8	Disconnected	0.00	0	0	0	0.00	0	0	0
9	Disconnected	0.00	0	0	0	0.00	0	0	0
10	Disconnected	0.00	0	0	0	0.00	0	0	0

Parameter description

Name		Description
Port		Specifies the ID of the port.
Port Rate		Specifies the connection rate and duplex mode of the port.
Sent	Rate	Specifies the sending rate of the port.
	Bytes	Specifies the total number of bytes sent by the port.
	Packets	Specifies the total number of packets sent by the port.
	Wrong Packets	Specifies the total number of wrong packets sent by the port.
Received	Rate	Specifies the receiving rate of the port.
	Bytes	Specifies the total number of bytes received by the port.
	Packets	Specifies the total number of packets received by the port.
	Wrong Packets	Specifies the total number of wrong packets received by the port.

14.4 Cable testing

Using cable testing, you can get a picture of the cable status of each port on the switch (such as whether the cable is disconnected or damaged). This helps you further locate and diagnose network failures.

Procedure:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **Switching > Cable Testing**.
3. Click **Select Port**, select ports to be detected, and then click **Start**.

---End

Wait until the testing results appear.

Cable Testing ?			Select Port	Stop
Port	Result	Status		
1	Disconnected	Cable disconnected or damaged		
2	Disconnected	Cable disconnected or damaged		
3	Normal	Cable connected		
4	Disconnected	Cable disconnected or damaged		
5	Disconnected	Cable disconnected or damaged		
6	Disconnected	Cable disconnected or damaged		
7	--	--		
8	--	--		
9	--	--		
10	--	--		

14.5 Jumbo frames

Through the jumbo frame function, the data transmission capacity of the port can be increased, thereby improving link utilization and obtaining better network performance.

On the **Switching > Jumbo Frames** page, you can enable or disable jumbo frames on the switch. This function is disabled by default. When it is enabled, the size of packets sent or received by each port of the switch can be increased to 3072 bytes.

14.6 EEE

Enabling EEE (Energy-Efficient Ethernet) reduces switch power consumption during low data transmission periods, optimizing energy efficiency.

On the **Switching > EEE** page, you can enable or disable EEE. This feature is disabled by default.

Click **Edit** to enable or disable EEE for multiple ports at once. Toggle the button under **Status** to enable or disable EEE for a specific port.

Energy Efficient Ethernet ?		Edit
Port	status	
1	<input type="checkbox"/>	
2	<input type="checkbox"/>	
3	<input type="checkbox"/>	
4	<input type="checkbox"/>	
5	<input type="checkbox"/>	
6	<input type="checkbox"/>	

15 Network security


Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

15.1 IGMP snooping

15.1.1 Overview

Internet Group Management Protocol Snooping (IGMP snooping) is a multicast restriction mechanism that runs on layer-2 Ethernet switches and is used to manage and control multicast groups.


As shown in the figure below, multicast data is broadcasted from the IGMP snooping-disabled layer-2 device; But with IGMP snooping enabled, the layer-2 device will establish a mapping table for ports and multicast MAC addresses by analyzing IGMP packets, and forward multicast data to the specific receiver.



IGMP snooping only forwards data to the specific receivers through the layer-2 multicast, providing the following advantages:

- Reduce broadcast in layer-2 network and saves network bandwidth.
- Enhance the security of multicast data.
- Provide convenience for charging management to each host.

As shown in the following figure, router A is connected to the multicast source, IGMP snooping is enabled on switch A and switch B, while host A and host C are the receivers of the multicast data.



■ Router port

On an IGMP-snooping-enabled layer 2 device, the ports toward upstream layer 3 multicast devices are called router ports (Ports A1 and B1 in the above figure).

■ Member port

On an IGMP-snooping-enabled layer 2 device, the ports toward downstream receiver hosts are called host ports (Ports A2, A4 and B2 in the above figure).

■ General query

The IGMP querier (router A in the above figure) periodically sends IGMP general queries to all hosts and devices in the local network segment to check the multicast group members.

After receiving an IGMP general query, the layer 2 device (switches A and B in the above figure) forwards the query, and performs the following treatment to the receiving ports:

- If the receiving port is included in the mapping table, the layer 2 device restarts the aging timer for the port.
- If the receiving port is excluded in the mapping table, the layer 2 device adds the port to the mapping table and starts an aging timer for the port

■ Specific query


When a host with enabled IGMPv2 or IGMPv3 leaves the multicast group, it sends IGMP leave group packets. When the ports of the layer-2 devices (switches A and B in the above figure) receive the IGMP leave group message, the following actions will be done based on the mapping table:

- If no forwarding entry of the multicast group is found or the matching forwarding entry does not contain the receiving port, the layer 2 device discards the IGMP leave group message directly instead of forwarding it to other ports.
- If the forwarding entry of the multicast group is found, and the matching forwarding entry contains other host ports, the layer 2 device discards the IGMP leave group message directly instead of forwarding it to other ports, and sends an IGMP specific query message to the leaving host.
- If the forwarding entry of the multicast group is found, and the matching forwarding entry does not contain other host ports, the layer 2 device forwards the message through the router port and also sends an IGMP specific query message to the host.

15.1.2 Configure IGMP snooping

On the **Network Security > IGMP Snooping** page, you can configure IGMP snooping on the switch.

This function is disabled by default. When it is enabled, the page is displayed as follows.



Parameter description

Name	Description
IGMP Snooping	Used to enable or disable IGMP snooping.
IGMP Fast Leave	Used to enable or disable IGMP fast leave. When it is enabled, when the switch receives an IGMP leave group message from a host to leave a multicast group, it directly deletes the port from the corresponding IGMP snooping multicast forwarding table without waiting for the host port aging time to expire.

Name	Description
IGMP Report Suppression	Used to enable or disable IGMP report suppression. When it is enabled, the switch forwards only the first IGMP report message for each multicast group to the IGMP querier within a query interval, and suppresses subsequent IGMP report packets for the same multicast group. This function prevents duplicate report packets from being sent to IGMP queriers.

15.1.3 View multicast forwarding table and route table

On the **Network Security > IGMP Snooping** page, you can view the multicast forwarding table in the **Multicast Forwarding Table** module and the route ports for multicast forwarding in the **Route Ports** module.

Multicast Forwarding Table		
IP Address	VLAN ID	Port
No Data		
		Total: 0
Route Ports		
Port Type	Port	
Dynamic	--	

Parameter description

Name	Description	
Multicast Forwarding Table	IP Address	Specifies the IP address of the multicast group.
	VLAN ID	Specifies the VLAN ID of the multicast group.
	Port	Specifies the member port of the multicast group.
Route Ports	Port Type	Specifies the type of the routing port of the multicast group. Only dynamic routing ports are displayed currently.
	Port	Specifies the routing port of the multicast group.

15.2 MAC tables

15.2.1 Overview

A MAC address table is used by the switch to record the correspondence between MAC addresses, ports, and the VLANs that the ports belong to. The switch automatically generates dynamic MAC address entries by learning source MAC addresses. Administrators can manually

add static MAC address tables. Only dynamic MAC address table entries are subject to [aging time limits](#).

The switch forwards messages according to the MAC address table, improving network communication efficiency.

15.2.2 Quickly bind static/allowed MAC addresses



This function may be unavailable for some models. The actual web user interface prevails.

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **Network Security > MAC Tables**, and select the **MAC Table** tab.
3. Locate the target device and click **Bind**. The following figure is for reference only.

MAC Address	VLAN ID	Type	Port	Operation
	1	Dynamic	3	Bind Delete
	1	Dynamic	3	Bind Delete
1c:fd:08:70:8f:cd	1	Dynamic	14	Bind Delete
	1	Dynamic	3	Bind Delete
	1	Dynamic	3	Bind Delete
	1	Dynamic	3	Bind Delete

4. Select **Static MAC** or **Allowed MAC** as required, and click **OK**.

Bind

☐ Static MAC ☐ Allowed MAC

Checking means binding, unchecking means canceling binding.

Cancel OK

---End

15.2.3 Manually add static MAC addresses



This function may be unavailable for some models.

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **Network Security > MAC Tables**, and select the **Static MAC Table** tab.
3. Click **Add**.

MAC Tables ?

Static MAC Table Allowed MAC Table MAC Table

Add Delete

MAC Address	VLAN ID	Port	Operation
No Data			

Total: 0

4. Configure the static MAC table, and click **OK**.

Static MAC Binding

MAC Address

VLAN ID

Select Port

Cancel OK

---End

After configuration, you can view the static MAC address entries in the [MAC table](#).

Parameter description

Name	Description
MAC Address	Specifies the MAC address. Format: XX:XX:XX:XX:XX:XX, XXXX-XXXX-XXXX or XXXXXXXXXXXX.
VLAN ID	Specifies the VLAN to which the MAC address belongs.

Name	Description
Port	Specifies the physical port of the switch where the MAC address resides.

15.2.4 Manually add allowed MAC addresses

After a MAC address is bound to a switch port, the switch port only allows the specific client to access.



Note

- Configuration errors may cause the switch or its clients to be disconnected from the network. Operate with caution.
- This function may be unavailable for some models.

Procedure:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **Network Security > MAC Tables**, and select the **Allowed MAC Table** tab.
3. Click **Add**.

4. Enter the target MAC address, select ports, and click **OK**.

---End

Parameter description

Name	Description
MAC Address	Specifies the MAC address of the client bound to the switch port. Format: XX:XX:XX:XX:XX:XX, XXXX-XXXX-XXXX or XXXXXXXXXXXX.
Port	Specifies the physical port of the switch where the MAC address resides.

15.2.5 View and delete MAC address entries

To access the page:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **Network Security > MAC Tables**, and select the **MAC Table** tab.



MAC Tables ?

Static MAC Table Allowed MAC Table **MAC Table**




MAC Address ⓘ VLAN ID Select Port


MAC Address ↕	VLAN ID ↕	Type ↕	Port ↕	Operation
<input type="text"/>	1	Dynamic	3	Bind Delete
<input type="text"/>	1	Dynamic	3	Bind Delete
<input type="text"/>	1	Dynamic	14	Bind Delete
<input type="text"/>	1	Dynamic	3	Bind Delete
<input type="text"/>	1	Dynamic	3	Bind Delete
<input type="text"/>	1	Dynamic	3	Bind Delete

Query parameters and buttons description

Name	Description
MAC Address	<p>Enter the MAC address to be queried.</p> <p> Tip</p> <p>You can fuzzy query for MAC address with at least 2 consecutive bytes. Format: XX-XX, XX: XX or XXXX.</p>
VLAN ID	<p>Enter the VLAN ID that the MAC address to be queried belongs to.</p> <p>Available only when 802.1Q VLAN is enabled.</p>
Select Port	<p>Enter the physical port of the switch where the MAC address to be queried is located.</p>
	<p>Enter keywords in the MAC address, VLAN ID, and port selection input boxes, and click this button to query the MAC address entry in a fuzzy or exact manner.</p>

Parameters and other buttons description


Name	Description
MAC Address	<p>Specifies the MAC address in the format XX:XX:XX:XX:XX:XX.</p>
VLAN ID	<p>Specifies the VLAN ID that the MAC address belongs to.</p>
Type	<p>Specifies the type of the MAC address.</p> <ul style="list-style-type: none">– Static: MAC address entry manually configured by the administrator.– Dynamic: MAC address entry automatically generated by the switch. <p> Tip</p> <p>The dynamic MAC address starts timing when it is added to the MAC table. If each port does not receive data with the source address of the MAC address within the aging time of 300 seconds, the address will be deleted from the MAC table.</p>
Port	<p>Specifies the physical port of the switch where the MAC address resides.</p>
	<p>Used to delete all MAC address entries on the current page.</p>
	<p>Used to delete all dynamic MAC address entries on the current page.</p>

Name	Description
Bind	<p>Used to quickly bind the MAC address to the static MAC table or allowed MAC table.</p> <p> Tip</p> <p>This function may be unavailable for some models.</p>

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

16.1 Port rate limit

On the **QoS > Port Rate Limit** page, you can set the suppression value of each port for receiving broadcast, multicast and unknown unicast packets, and configure the ingress and egress rates of the port.

Port Rate Limit 							Edit
Port	Broadcast Suppression	Multicast Suppression	Unknown Unicast Suppression	Suppression Value	Egress Rate	Ingress Rate	
1	Disable	Disable	Disable	100	0	0	
2	Disable	Disable	Disable	100	0	0	
3	Disable	Disable	Disable	100	0	0	
4	Disable	Disable	Disable	100	0	0	
5	Disable	Disable	Disable	100	0	0	
6	Disable	Disable	Disable	100	0	0	
7	Disable	Disable	Disable	100	0	0	
8	Disable	Disable	Disable	100	0	0	
9	Disable	Disable	Disable	100	0	0	
10	Disable	Disable	Disable	100	0	0	

Parameter description

Name	Description
Port	Specifies the ID of the port.
Broadcast Suppression	Used to enable or disable broadcast suppression. It is disabled by default. No Change indicates that the function status remains unchanged.
Multicast Suppression	Used to enable or disable multicast packet suppression. It is disabled by default. No Change indicates that the function status remains unchanged.

Name	Description
Unknown Unicast Suppression	Used to enable or disable unknown unicast suppression. It is disabled by default. No Change indicates that the function status remains unchanged.
Suppression Value	Used to set the maximum broadcast, multicast or unknown unicast packet allowed to pass through the port per second. When broadcast, multicast or unknown unicast packets exceeds the suppression value, these extra packets will be discarded, thereby reducing the proportion of broadcast, multicast or unknown unicast traffic on the port to a limited range, and ensuring network service. For example, if broadcast suppression and multicast suppression are enabled on a port and the suppression value is set to 100, then the broadcast and multicast packet traffic allowed to pass through the port per second will be 100 Mbps, and the exceeding packets will be discarded.
Egress Rate	Specifies the maximum sending rate of the port. -- indicates no rate limit. When the maximum sending rate is exceeded, packets are queued according to QoS policies to ensure efficient bandwidth allocation and utilization.
Ingress Rate	Specifies the maximum receiving rate of the port. -- indicates no rate limit. When the maximum sending rate is exceeded, packets are queued according to QoS policies to ensure efficient bandwidth allocation and utilization.

16.2 QoS policies

16.2.1 Overview

In traditional IP network, packets are treated equally. This network service policy is known as Best-effort, which delivers the packets to their destination with the best effort, with no assurance and guarantee for delivery delay, reliability, and so on. Nowadays, in addition to traditional applications such as www, FTP and E-mail, new services occur, such as video conference, remote education, Video-on-Demand (VoD) and video telephone, which need higher requirements of bandwidth, delay and jitter. Quality of Service (QoS) policy can meet the above demands and improve the quality of service in the network.


This switch classifies the packets based on priority at the ingress stage, then maps them to different queues at the egress stage, and finally forwards these packets by queues based on the scheduling mode, so as to guarantee the quality of network service.

Scheduling mode

Queue scheduling is used to solve the problem of resource preemption by multiple packets when the network is congested. This switch supports three scheduling modes: strict priority,

simple weighted priority and weighted priority. Each scheduling mode has eight queues to determine the data forwarding priority.

■ **Strict priority**



Strict priority scheduling algorithm is specially designed for critical service applications. An important feature of critical services is that they demand preferential service in congestion in order to reduce the response delay.

In queue scheduling, the packets are sent in queues strictly following the priority order from high to low (Queue 7 > Queue 6 > ... > Queue 0). When the queue with higher priority is empty, packets in the queue with lower priority are sent. You can put critical service packets into the queues with higher priority and put non-critical service packets (such as E-mail) into the queues with lower priority. In this way, critical service packets are sent preferentially, and non-critical service packets are sent when the critical service packets are not sent.

But there is a downside to this scheduling algorithm. If there are packets in the queues with higher priority for a long time during congestion, the packets in the queues with lower priority will keep stuck because they are not served.


■ **Simple weighted priority**

In this mode, there is no priority and all queues equally share the bandwidth.

■ **Weighted priority**

This scheduling algorithm schedules all the queues in turn to ensure that every queue can be assigned a certain service time. The weighted value stands for the proportion of assigned resource. Assuming there are eight output queues for a port, and each queue is assigned with a weighted value. For instance, you can configure the eight weighted values of a 100 Mbps port to 25, 20, 15, 15, 10, 5, 5 and 5 respectively. In this way, the queue with the lowest priority can

be assured of 5 Mbps of bandwidth at least, thus avoiding the disadvantage of Simple Priority queue-scheduling algorithm that packets in low-priority queues are possibly not to be served for a long time. Another advantage of Weighted Priority queue-scheduling algorithm is that though the queues are scheduled in turn, the service time for each queue is not fixed, which means if a queue is empty, the next queue will be scheduled immediately. In this way, the bandwidth resources can be fully utilized.



Priority


This switch supports three priority modes: [802.1P priority](#), [DSCP priority](#), and [port priority](#).

- **802.1P priority**

802.1P priority lies in Layer 2 packet headers and applies to occasions where the Layer 3 packet header does not need analysis but QoS must be assured at Layer 2. 802.1P priority is available only in an 802.1Q tagged packet. As seen below, the 4-byte 802.1Q tag contains a 2-byte Tag Protocol Identifier (TPID, value: 0x8100) and a 2-byte Tag Control Information (TCI).

Destination Address	Source Address	802.1Q header		Length/Type	Data	FCS (CRC-32)
		TPID	TCI			
6 bytes	6 bytes	4 bytes		2 bytes	46~1500 bytes	4 bytes

The figure below displays a detailed view of an 802.1Q tag. The field **Priority** under TCL is the 802.1P priority, which consists of 3 bits ranging from 0 to 7.




By default, the 802.1P priority, queues, and key words of this switch are mapped as follows.

802.1P priority	Queue	Key word
0	0	best-effort
1	1	background
2	2	spare
3	3	excellent-effort
4	4	controlled-load
5	5	video
6	6	voice
7	7	network-management

■ DSCP priority

RFC2474 re-defines the Type of Service (ToS) field in the IP message header, which is called the Differentiated Services (DS) field. The first six bits (bits 0 to 5) of the DS field indicate Differentiated Services Codepoint (DSCP) priority ranging from 0 to 63. The last 2 bits (bits 6 and 7) are reserved.



The mapping between the DSCP priority and key words are as follows.

DSCP priority (decimal)	DSCP priority (binary)	Key word
46	101110	ef

DSCP priority (decimal)	DSCP priority (binary)	Key word
10	001010	af11
12	001100	af12
14	001110	af13
18	010010	af21
20	010100	af22
22	010110	af23
26	011010	af31
28	011100	af32
30	011110	af33
34	100010	af41
36	100100	af42
38	100110	af43
8	001000	cs1
16	010000	cs2
24	011000	cs3
32	100000	cs4
40	101000	cs5
48	110000	cs6
56	111000	cs7
0	000000	be (default)

By default, the DSCP priority and queues of this switch are mapped as follows.

DSCP priority	Queue
0 - 7	0
8 - 15	1

DSCP priority	Queue
16 - 23	2
24 - 31	3
32 - 39	4
40 - 47	5
48 - 55	6
56 - 63	7

■ Port priority

You can manually configure the Class of Service (CoS) priority of physical ports to map the physical ports with queues. The port maps packets to the corresponding queues based on the configured mapping relationship when the following two situations occur:

- The packets received by the port do not carry the priority tags trusted by the port.
Example: For a port with 802.1P priority mode enabled, the received packets do not carry the 802.1Q tag.
- The port does not trust the 802.1P priority mode and DSCP priority mode.

The CoS priority of the ports and queues are mapped as follows.

CoS priority	Queue
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7

16.2.2 Configuration wizard

Based on 802.P priority

Step	Task	Description
1	QoS scheduling	Required. Select the scheduling mode of the switch based on actual demands.
2	802.1P	Required. Configure the mapping relation between 802.1P priority and queues.
3	QoS ports	Required. Set the priority mode of corresponding ports to 802.1P Trust and configure the CoS priority for all ports.

Based on DSCP priority

Step	Task	Description
1	QoS scheduling	Required. Select the scheduling mode of the switch based on actual demands.
2	DSCP	Required. Configure the mapping relation between DSCP priority and queues.
3	QoS ports	Required. Set the priority mode of corresponding ports to DSCP Trust and configure the CoS priority for all ports.

Based on CoS priority

Step	Task	Description
1	QoS scheduling	Required. Select the scheduling mode of the switch based on actual demands.
2	QoS ports	Required. Set the priority mode of corresponding ports to No Trust and configure the CoS priority for all ports.

16.2.3 Configure QoS settings

QoS scheduling

On the **QoS > QoS Configuration > QoS Scheduling** page, you can configure the QoS scheduling mode.

QoS Configuration ?

QoS Scheduling 802.1P DSCP

QoS Scheduling Algorithm Simple Weighted Priority ▼

Save

Parameter description

Name	Description
QoS Scheduling Algorithm	<p>Specifies the QoS scheduling algorithm for the port traffic.</p> <ul style="list-style-type: none">– Strict Priority: The switch forwards the packets strictly based on the priority from high to low. The queue packets with the lower priority are forwarded only when the queue with higher priority is empty.– Simple Weighted Priority: 8 queues equally share the bandwidth.– Weighted Priority: You need to configure a weighted value for each queue. The weighted value indicates the weight of obtaining resources. If congestion occurs on the port, the bandwidths are assigned based on the weight of each queue.
Queues	<p>If the QoS Scheduling Algorithm is set to Weighted Priority, you need to configure the weighted value for each queue.</p>

802.1P

On the **QoS > QoS Configuration > 802.1P** page, you can configure the mapping relationship between the 802.1P priority and queues.

QoS Configuration ?

QoS Scheduling
802.1P
DSCP

CoS0

Q0

CoS1

Q1

CoS2

Q2

CoS3

Q3

CoS4

Q4

CoS5

Q5

CoS6

Q6

CoS7

Q7

Save

Parameter description

Name	Description
Q0	Specifies the queue in which the VLAN packets' priority is 0.
Q1	Specifies the queue in which the VLAN packets' priority is 1.
Q2	Specifies the queue in which the VLAN packets' priority is 2.
Q3	Specifies the queue in which the VLAN packets' priority is 3.
Q4	Specifies the queue in which the VLAN packets' priority is 4.
Q5	Specifies the queue in which the VLAN packets' priority is 5.
Q6	Specifies the queue in which the VLAN packets' priority is 6.
Q7	Specifies the queue in which the VLAN packets' priority is 7.

DSCP

On the **QoS > QoS Configuration > DSCP** page, you can configure the mapping relationship between the DSCP priority and queues.

QoS Configuration ?

QoS Scheduling

802.1P

DSCP

DSCP	Port Queue	DSCP	Port Queue	DSCP	Port Queue	DSCP	Port Queue
0	<div>Queues0 ▾</div>	16	<div>Queues2 ▾</div>	32	<div>Queues4 ▾</div>	48	<div>Queues6 ▾</div>
1	<div>Queues0 ▾</div>	17	<div>Queues2 ▾</div>	33	<div>Queues4 ▾</div>	49	<div>Queues6 ▾</div>
2	<div>Queues0 ▾</div>	18	<div>Queues2 ▾</div>	34	<div>Queues4 ▾</div>	50	<div>Queues6 ▾</div>
3	<div>Queues0 ▾</div>	19	<div>Queues2 ▾</div>	35	<div>Queues4 ▾</div>	51	<div>Queues6 ▾</div>
4	<div>Queues0 ▾</div>	20	<div>Queues2 ▾</div>	36	<div>Queues4 ▾</div>	52	<div>Queues6 ▾</div>
5	<div>Queues0 ▾</div>	21	<div>Queues2 ▾</div>	37	<div>Queues4 ▾</div>	53	<div>Queues6 ▾</div>
6	<div>Queues0 ▾</div>	22	<div>Queues2 ▾</div>	38	<div>Queues4 ▾</div>	54	<div>Queues6 ▾</div>

Parameter description

Name	Description
DSCP	Specifies the priority level defined by DS field of the IP packet heads. Range: 0-63.
Port Queue	Specifies the DSCP priority of the queue.

16.2.4 Configure QoS ports

On the **QoS > QoS Ports** page, you can configure the priority mode and the CoS priority of each physical port on the switch.

QoS Ports ?

Trust Mode

No Trust ▾

Edit

Port	CoS Priority
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0

Parameter description

Name	Description
Trust Mode	<p>Specifies the method which the port uses to process the received packets.</p> <ul style="list-style-type: none">– No Trust: All packets received by the port rejoin queues based on the correspondence of the configured CoS priority.– 802.1P Trust: When the port receives VLAN packets, the packets rejoin queues based on the correspondence of the 802.1P. When the port receives other packets, the packets rejoin queues based on the correspondence of the CoS priority.– DSCP Trust: When the port receives IP packets, the packets rejoin queues based on the correspondence of the DSCP. When the port receives other packets, the packets rejoin queues based on the correspondence of the CoS priority.
Port	<p>Specifies the ID of the port.</p>
CoS Priority	<p>Specifies the CoS priority of the physical ports. When the switch receives packets not in accordance with the trust mode rules or the port is in No Trust mode, the packets rejoin queues based on the CoS priority.</p>

17 Manage PoE

-
- Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.
 - This function is only available for product models that contain a "P" letter. Unless otherwise specified, G2206P-4-63W is used for illustration in this chapter.
-

PoE (Power over Ethernet, also known as remote power supply) means that the device delivers power to powered devices such as IP phones, wireless APs and IP cameras through Ethernet cables.

PoE ports on the switch can automatically detect powered devices and supplies PoE power to the powered devices that comply with the IEEE 802.3af and IEEE 802.3at standards.

By default, the PoE function is enabled on PoE ports.

17.1 View PoE budget and consumption

To access the page:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **PoE Management** and select the **PoE Configuration** tab.

17.2 Enable/Reboot PoE schedule



- To ensure that this function works properly, [connect the switch to the IP-COM ProFi cloud platform](#) to ensure that the system time is correctly synchronized.
 - This function takes effect only when PoE is turned on the **PoE Management > Port Settings** page.
-

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **PoE Management**, select the **Period Setting** tab, and click **Add** to add PoE schedules.
 - **Select Port:** Select ports that you apply the PoE schedule to.

- **Applied:** Select the PoE schedule to apply.
- **Start/End Time:** Select the time period for the PoE schedule to take effect.
- **Repeat:** Select dates for the PoE schedule to repeat.

---End

If other ports need to apply this PoE schedule policy, make changes on this page or click **Edit** on the **PoE Management > Port Settings** page.

17.3 Change PoE port settings

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **PoE Management**, and select the **Port Settings** tab.
3. Click **Edit** to batch change, or change settings of a single port in **Port Settings**. The following figure is for reference only.

PoE Usage

Refresh

58W
Total

0.00W
Used

58.00W
Remaining

Enable PoE Watchdog

Port Settings

Edit

Port	Power	PoE	PoE Reboot	PoE Standard	PoE Schedule
1	0.00			AF	1

---End

On port 1, IEEE 802.3at PoE is enabled and the PoE schedule policy "1" is applied.

Parameter description

Name	Description
Enable PoE Watchdog	The switch continuously monitors inbound traffic on PoE ports connected to powered devices. If none is detected for a period of time, the port's power is briefly cut and restored.

17.4 Change fan mode

Some high-power PoE switches dissipate heat through built-in fans. Adaptive is the default fan mode. To change the fan mode, take the following steps:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **PoE Management**, and select the **PoE Configuration** tab.
3. Select the fan mode. The following figure shows how to set Forced mode on G2220P-16-250W.

– **Adaptive:** When the PoE output exceeds a certain power, the fan automatically runs to dissipate heat from the switch. When the output drops, the fan automatically stops.

– **Forced:** The fan constantly runs to dissipate heat from the switch.

PoE Usage

230W
Total

3.87W
Used

Enable PoE Watchdog

Fan Mode ?

Adaptive

Port Settings

Forced

Adaptive


---End

18 Control indicators

Features available in the switch may vary by model and software version. Switch availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual experience.

The switch indicators are on by default, providing a visual status of the device's operation. When off, the indicators will not indicate the operation status.

To turn the switch indicators on or off, follow these steps:

1. On a computer connected to the switch port belonging to the management VLAN, open a browser and enter the switch's IP address ([management IP](#) or [dynamic IP](#)) in the address bar.
2. Navigate to **System Settings > Indicator**.
3. Turn the indicators on or off using the toggle .
4. Click **Save**.

---End

All indicators are on or off.

Appendix

Acronyms and Abbreviations

Acronym or Abbreviation	Full Spelling
CoS	Class of Service
CPU	Central Processing Unit
DHCP	Dynamic Host Configuration Protocol
DNS	Domain Name System
DSCP	Differentiated Services Code Point
EEE	Energy-Efficient Ethernet
ID	Identity Document
IGMP	Internet Group Management Protocol
IP	Internet Protocol
MAC	Medium Access Control
PD	Powered Device
PoE	Power over Ethernet
PVID	Port-base VLAN ID
QoS	Quality of Service
RMON	Remoter Monitoring
RSTP	Rapid Spanning Tree Protocol
SNMP	Simple Network Management Protocol
TCI	Tag Control Information

Acronym or Abbreviation	Full Spelling
TCP	Transmission Control Protocol
ToS	Type of ServiceS
TPID	Tag Protocol Identifier
UDP	User Datagram Protocol
VLAN	Virtual Local Area Network